





RTX SUBSCRIPTION RENEWALS

THIS HOW-TO GUIDE IS FOR ENTERING RANGEPOINT RTX AND CENTREPOINT RTX SUBSCRIPTION CODES INTO AN AG-372 RECEIVER WITH AN INTELLI-VIEW IV INSTALLED.


HOW TO GUIDE:




1) From the main screen, click TOOLBOX.




2) On the bottom tabs click GPS. Scroll down to ACTIVATION CODE.




3) Click on the ACTIVATION CODE text box to enter code.




4) Enter your activation code provided. Use the ABC button for more letter options. Click ENTER.




5) Click ACTIVATE. You should get a message to say 'Unlock was Successful'. If not, check that the code and serial number were correct. *Find the serial number above the ACTIVATION CODE box.




6) Scroll back up to the top settings. Under CORRECTION TYPE select your correction; RangePoint RTX or CentrePoint RTX.



7) Under RTX SETUP OPTIONS select option depending on your firmware level. For v8.30 or later, select AUTO. For earlier versions, go to step 8).



8) Under RTX SETUP, click EDIT.




9) Check the following: RTX SATELLITE FREQUENCY =1539.8325 RTX BAUD RATE =600 If correct, click OK.

IF YOU ARE USING RANGEPOINT RTX, SETUP IS NOW COMPLETE. IF YOU ARE USING CENTREPOINT RTX, CONTINUE TO STEP 10).



10) Under CORRECTION LEVEL, select RTX/SAT-STD.



11) Under POSITION RECALL, select ENABLE.

ALLOW AROUND 15MINS TO CONVERGE TO 30CM AND DGPS STEERING. SETUP IS NOW COMPLETE